

CMT-M333NT

SERVICE MANUAL



Ver 1.1 2003. 05

Canadian Model
AEP Model
UK Model
E Model
Chinese Model
Australian Model

- CMT-M333NT is composed of following models.
As for the service manual, it is issued for each component model, then, please refer to them.

COMPONENT MODEL NAME

	CMT-M333NT
COMPACT DISK DECK RECEIVER SYSTEM	HCD-M333
SPEAKER SYSTEM	SS-CM333

SPECIFICATIONS

General

Power requirements

North American model:	120 V AC, 60 Hz
European model:	230 V AC, 50/60 Hz
Korean model:	220 V AC, 60 Hz
Chinese model:	220 V 50/60 Hz
Other models:	220 – 240 V AC, 50/60 Hz
Power consumption	
European model:	65 W
	0.3 W or less (in Power Saving mode)
Other models:	65 W

Dimensions (w/h/d) incl. projecting parts and controls
Amplifier/Tuner/Tape/MD/CD section:

Approx. 160 × 217 × 345
mm

Speakers: Approx. 140 × 217 × 247
mm

Mass

Amplifier/Tuner/Tape/MD/CD section:

Approx. 5.6 kg

Speakers: Approx. 2.3 kg net per speaker

Supplied accessories
Remote commander (1)
R6 (size AA batteries) (2)
FM wire aerial (1)
AM loop aerial (1)
USB cable (1)
Operating Instructions (1)
M-crew/SonicStage for
Net MD CD-ROM (1)
Warranty (1)
(EXCEPT Hong Kong model)

Design and specifications are subject to change
without notice.

PARTS LIST

<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
ACCESORIES		

1-476-970-12	COMMANDER,STANDARD (RM-SM100EW)	
1-501-374-12	ANTENNA, LOOP (EXCEPT CND)	
1-501-594-34	ANTENNA (EXCEPT CND)	
1-754-059-12	ANTENNA, LOOP (AM)(CND)	
1-793-184-22	CONNECTOR (F TYPE ADAPTOR)(FM)(CND)	
1-823-975-11	CORD, CONNECTION (USB)	
4-233-609-11	COVER, BATTERY (FOR RM-SM100EW)	
4-243-237-12	MANUAL, INSTRUCTION (ENGLISH)(CND,AEP,UK,HK,AUS)	
4-243-237-22	MANUAL, INSTRUCTION (FRENCH,SPANISH)(CND,AEP)	
4-243-237-31	MANUAL, INSTRUCTION (GERMAN,DUTCH,ITALIAN)(AEP)	
4-243-237-41	MANUAL, INSTRUCTION (SWEDISH,PORTUGUESE)(AEP)	
4-243-237-51	MANUAL, INSTRUCTION (TRADITIONAL CHINESE)(HK)	
4-243-237-81	MANUAL, INSTRUCTION (KOREAN)(KR)	
4-245-609-01	CD-ROM (M333NT-CE) (M-crew, SonicStage)	

• Abbreviation

CND : Canadian model.

HK : Hong Kong model.

KR : Korea model.

CH : Chinese model.

AUS : Australian model.

The components identified by mark ▲ or dotted line with mark ▲ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ▲ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

MICRO HI-FI COMPONENT SYSTEM

9-877-179-02

Sony Corporation

2003E16-1

Home Audio Company

© 2003.05

Published by Sony Engineering Corporation

SONY®